

## **Cleaning Maintenance:**

For maximum life of Celina fabrics, Celina recommends regular cleaning. For most types of dirt (pollen & diesel fumes) it is recommended to use Celina's Tent Cleaner that was developed for tents and sidewalls. It can be used with a garden hose while tent is erect or manually while tent is spread on flat surface. Other neutral soaps and cleaners such as ivory dish soap or Spic' N' Span and warm water are also accepted. Thorough rinsing and drying is required before storing them.

## **Stain Remover:**

Celina has several different stain removers to choose from. The Celina Citrus Cleaner is a 100% biodegradable solvent that quickly removes adhesive residue from tents, inflatable bouncers, PVC, and plastics. This cleaner completely cleans and removes: Engine Grease, tar / asphalt, paints / inks, glue / adhesive, shoe Polish, tape residue, lipstick / crayon, kitchen grease, and chewing gum. A diluted bleach solution of at least 1:5 in water can be used when general maintenance cleaning will not remove the stain. Isopropyl alcohol or mineral spirits are also helpful in removing gummy residue or wet paint. Be sure to remove excess with a clean, dry cloth.

## **Things that will cause premature degradation and reduced life expectancy of your tents:**

- Extended use of the tent without cleaning
- Accumulation of dirt on the vinyl surface will promote the growth of mold and mildew and premature wear.
- Storage of vinyl that has not been dried thoroughly
- Even a slightly damp product can promote the growth of mildew when folded and stored. Mold and/or mildew may require harsh cleaners to remove, which may cause premature wear. The best solution is to take every precaution to keep mold and mildew from growing in the first place.
- Harsh Detergents and Cleaners, which contain a Solvent or Bleach
- The longer the exposure of PVC vinyl to these products, the more it will reduce the life of the PVC vinyl. If you or your customer decides to use a product containing a solvent or bleach, it is very important to remove it as quickly as possible, rinsing thoroughly and drying.
- High Abrasive Cleaners, including Wire Brushes, Power Washers and/or Commercial Washing Machines will result in premature wear and deterioration of tent fabrics.
- During installation/dismantling tents or canopies improper handling such as on a rough surface can create pinholes and abrasions.
- Wind whip will also damage the tent.

## **VINYL CLEANER**

First impressions are important; therefore, make your tents shine with our vinyl cleaning products. Many rental companies rely on referrals to increase their business so make sure your tent is clean and mildew free for your next event. Please visit [GetTent.com](http://GetTent.com) for more information on our cleaning products.

## **VINYL REPAIR**

Avoid an embarrassing situation by being prepared for small accidents that can happen in the field during tent installations. Celina's repair products provide a quick and easy applicable solution to small tears and puncture holes when there is no time to spare. Our repair kits are equipped with multiple colors for versatility in the field. Please visit [GetTent.com](http://GetTent.com) for more information on our vinyl repair products.



### **CUSTOMER SUPPORT**

If you have any questions, please contact Celina Tents support department at:

[support@celinatent.com](mailto:support@celinatent.com)

1-866-GET-TENT /419-586-3610

[www.GetTent.com](http://www.GetTent.com)