



Assembly Instructions

1.



Place contents of box on floor or table. Place handle over riser tube with decal facing up and insert short 3/8" - 24 bolt.

2.




Start 3/8"-24 self locking nut on to bolt.

3.




Swing link arms up to handle. Insert the long 3/8"-24 bolt through link arms and handle. Install flat washer on bolt. Start 3/8"-24 locking nut on bolt.

4.



Use two 9/16" wrenches to tighten riser bolts and nuts and link arms onto handle. Note: Nut will stop before contacting the handle.



Operating Instructions

1. Remove screws or nails from stake and form.
2. Lift handle to up position so that jaws are fully open.
3. Place unit so that jaws are on either side of the stake. Figure 1 below.
4. Push down on handle, clamping on stake and lifting it out of the ground. Figure 2 below.
5. Repeat motion as necessary until stake is free.

Tip: In soft conditions or mud, place a short piece (1 to 2 feet in length) of 2 x 4 lumber under the base of the unit. This will spread the force over a larger area, allowing stake removal even in muddy conditions.

1.



2.



Celina Tent Inc. / Celina Enterprises

Toll-Free: 866-438-8368 / 419-586-3610

5373 State Route 29, Celina, Ohio 45822

www.GetTent.com

A Division of CELINA TENT

Caution: Never put your fingers or hands between the jaws, or between the jaws and the stake.

Replacement jaws - 4 jaws & hardware - Part # CA0002

